

# Erik the Black's Ultralight Chess Set

[www.BlackwoodsPress.com/Blog/](http://www.BlackwoodsPress.com/Blog/)

## Instructions:

1. Print this page on card stock & cut out pieces with scissors
2. Draw 8" x 8" chess board on a 12" x 12" piece of Tyvek using a Sharpie
3. Store in quart sized ziplock baggy

**Note about wind:** This chess set works best in calm conditions. When it is windy your board and pieces can blow away. The 2 inch border on the board gives you room to anchor it with rocks or other objects. To make it wind-proof, use **Velcro Sticky-Back Hook & Loop Dot Fasteners** to attach the pieces to the board.

